

**AIS CUBE**

CONVERT



**[THE BLAZINGCORE SERIES]**

WITH SUPERIOR NUMBER CRUNCHING ABILITIES AND PERIPHERAL HANDLING ON OUR CUSTOM EMBEDDED OS,  
RAPID PROTOTYPING IS NOW EASY... AND BLAZING FAST.

# CONVERT

## CONVERT

Convert specific Data Types to Another Data Type.

Members	Description
<code>Int2Sng</code>	Convert an Integer Value to Data Type Single
<code>Sng2Int</code>	Convert a Single Value to Data Type Integer
<code>Str2Int</code>	Convert a number String to Data Type Integer
<code>Str2Sng</code>	Convert a number String Variable to Data Type Single

### .INT2SNG

Convert an Integer Value to Data Type Single

```
Variable = Convert.Int2Sng(ByVal Value As Integer) As Single
```

### .SNG2INT

Convert a Single Value to Data Type Integer

```
Variable = Convert.Sng2Int(ByVal Value As Integer) As Integer
```

### .STR2INT

Convert a number String to Data Type Integer

```
Variable = Convert.Str2Int(ByVal Value As Integer) As Integer
```

### .STR2SNG

Convert a number String Variable to Data Type Single

```
Variable = Convert.Str2Sng(ByVal Value As Integer) As Single
```

## LATEST DOCUMENTATION

All of our documentations are constantly updated to provide accurate and/or new information that we feel would help you with developing with our products.

The latest documentation may be obtained from our website: <http://www.aiscube.com/main/downloads.html>

## HOW YOU CAN HELP

You can help us to improve our documentations by emailing to us or posting a thread in our forum, reporting any mistakes/typos or errata that you might spot while reading our documentation.

Email: [TechSupport@aiscube.com](mailto:TechSupport@aiscube.com)

Forum: <http://forum.aiscube.com/index.php>

## DISCLAIMER

All information in this documentation is provided 'as-is' without any warranty of any kind.

The products produced by AIS Cube are meant for rapid prototyping and experimental usage; they are not intended nor designed for implementation in environments that constitute high risk activities.

AIS Cube shall assume no responsibility or liability for any indirect, specific, incidental or consequential damages arising out of the use of this documentation or product.

COPYRIGHT© 2009 - 2011 AIS CUBE. ALL RIGHTS RESERVED.

ALL PRODUCT AND CORPORATE NAMES APPEARING IN THIS DOCUMENTATION MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES. AND ARE ONLY USED FOR IDENTIFICATION OR EXPLANATION FOR THE OWNER'S BENEFIT. WITH NO INTENT TO INFRINGE.

SONATA IDE AND BLAZINGCORE(BCORE) ARE TRADEMARKS OF AIS CUBE IN SINGAPORE AND/OR OTHER COUNTRIES. ALL IMAGES DEPICTING THE BLAZINGCORE OR ANY PART OF IT IS COPYRIGHTED.

ALL OTHER TRADEMARKS OR REGISTERED TRADEMARKS ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS.